

SkyGuard™ Installation Kits


Attachments and Accessories

JLG
GROUND
SUPPORT®

AFTERMARKET PARTS

THE NEW STANDARD IN ENHANCED CONTROL PANEL PROTECTION

SkyGuard™ is the latest innovation from JLG that provides operators with enhanced control panel protection that doesn't limit platform workspace or visibility. When the sensor is activated, SkyGuard stops all functions in use at the time of activation and it's unique reverse functionality -- the first feature of it's kind in the market -- temporarily reverses most functions for a short period of time. SkyGuard is available as an aftermarket kit exclusively from JLG.




SkyGuard™

FEATURES / BENEFITS

- Can be activated from a variety of angles
- No moveable parts means there's no need for scheduled or additional maintenance
- A horn and optional blue flashing beacon alert other workers on the jobsite to sensor activation
- Kit includes all required components, hardware, and instructions

HOW TO ORDER:


- **ONLINE EXPRESS®**
- **Phone: (877) JLG-LIFT**
- **Fax: (800) 733-8939**



Operator moves toward obstruction.



Horn sounds upon operator contact with the bar.



The auto reverse feature activates for most functions.

Refer to following page for detailed application information.

Putting your work above everything.®

SkyGuard™ Installation Kits

Genuine JLG Parts



AFTERMARKET PARTS

1. Identify which ground control module your machine is equipped with by using the photographs on the right.
2. Refer to the chart below to determine which kit is applicable to your machine.

***Note:** Kits cannot be used in conjunction with any type of platform console cover.

Machine Model	Kit Type	Application	Part Number
400S/460SJ	Complete	S/N 0300077554 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
450A/AJ Series II	Complete	S/N 0300077555 to Present and S/N 1300000353 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
510AJ	Complete	S/N 1300000353 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
600A/AJ	Complete	S/N 0300077490 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
600S/SJ	Complete	S/N 0300077490 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
680S	Complete	All without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
740AJ	Complete	S/N 0300077500 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
800A/AJ	Complete	S/N 0300077251 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
800S/860SJ	Complete	S/N 0300079612 to Present without Universal Ground Module	1001149560
		All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
1100S/SJP, 1100SB	Complete	All	1001143669
	Platform Only	All	1001137672
1200SJP, 1350SJP	Complete	All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
1250AJP	Complete	All without Universal Ground Module	1001155077
	Complete	All with Universal Ground Module	1001143669
	Platform Only	All with Universal Ground Module	1001137672
1500SJ	Complete	All	1001143669
	Platform Only	All	1001137672



Non-UGM Ground Control Module



UGM Ground Control Module

***NOTE:**

Complete Kit for machines without Universal Ground Module contains Platform Sensor Installation, Optional Blue Beacon, and UGM Conversion.
Complete Kit for machines with Universal Ground Module contains Platform Sensor Installation and Optional Blue Beacon.

Optional Beacon Installation Kits for machines previously equipped with SkyGuard:

1001155079 - 1250AJP models with UGM SkyGuard retrofit

1001143256 - All models except 1250AJP with UGM SkyGuard retrofit

Putting your work above everything.®